


Door / Entry Station Part Numbers




7-A11S1-0-SM = Part number for a surface mounted silver metallic, 711 door station with an audio loudspeaker and one call button module with one button on it.



7-C11F1-H-TM = Part number for a Titanium metallic, 711 door station with color camera, an audio loudspeaker, one call button module with one button on it and an HID Proxpoint card reader.

Master / Internal Station Part Numbers



8-ASF-EG = Part number for a surface mounted gold paneled standard iDor handset.



S-CCD-W = Part number for a desktop mounted white station containing a privacy handset (DH3000), a Master Station (SIC3000), and a color monitor.